


# CAD Dual Arm Welding Fume Extractor Operating Principle



① Polluted Air Inlet


⑥ Ventilator Fan

② Settling Chamber

⑦ Clean-Air Exhaust

③ Front & Rear Hoppers

⑧ Air Tank



⑤ Cartridge Filters



The horizontal position of the cartridges allows for quick and easy removal.

