Explosion-proof Starters

in hazardous applications

Safe and reliable starting

ISO9001, UL508 & **UL1203 (NNNY) Certified Panel Shop Including ATEX Solutions**



Call Toll-Free: (800) 635-0298 sales@controlledairdesign.com



Explosion Proof motor control panel mounted directly to motor and pump frame.

Sprecher + Schuh offers explosionproof starters for environments covered by the following classifications:

NEMA: Type 4/4X, 7BCD, 9EFG

NEC: Class I, Div. 1 Groups B, C, D Class II, Div. 1 Groups E, F, G Class III

UL: Standard 1203 Hazardous (Classified)

Locations

CSA: Standard 22.2 No. 25 & 30

Explosion-proof combination starters also comply with NEMA Type 3, 3R, 4 & 4X. Optional ATEX certification is available in Class I, Zone 1, AExd I1B, Exd I1B+H2, IEXEx.


NEMA Type 4, 4X, 7, & 9 protection

NEMA Type 7 enclosures are designed to provide protection against an internal explosion when operated in a hazardous gas environment. NEMA Type 9 enclosures protect from internal explosion in a hazardous dust environment.

Both types must also prevent enclosed heat generating mechanisms from causing external surfaces to reach temperatures capable of igniting explosive gas-air mixtures in the surrounding atmosphere. Sprecher + Schuh explosion-proof starters meet all requirements of both classifications. Inclusive with the selection of these explosion proof starters is a gasket inserted into the flange of the enclosure. This included gasket also gives the enclosures a NEMA Type 4 watertight and NEMA Type 4X corrosion resistance approval.

Starting with the best

At the heart of all explosion-proof starters is Sprecher + Schuh's CAT7 and CAT9 line of motor starters. These starters are compact and offer intermediate sizes to better match specific motor requirements. This equates to generous wiring space and less wasted horsepower capacity.



Top line protection...

Explosion Proof starters are equipped with Sprecher + Schuh's CEP7 solid state overload relay standard. Unlike traditional overload relays that indirectly sense motor current through heater elements, CEP7 solid state overload relays measure motor current directly through integrated current transformers and on board electronics. The electronics provide numerous advantages over electromechanical relays.

Combination starters for protection and convenience

Explosion-proof combination starters can include either a UL489 approved Thermal Magnetic Circuit Breaker (MCCB) or non-fusible disconnect. The MCCB utilizes the instantaneous trip ability of a magnetic breaker for short circuit currents combined with the overload tolerance of thermal circuit breakers for normal starting demands. An MCCB can also be quickly reset after the fault has been cleared.

A molded case switch (MCS) is used in applications requiring only a non-fused disconnect.



Series CAT

Series CAT7 & CAT9 @

Maximum Horsepower Three Phase			ower	Without Short Circuit Protection	D I M	MCCB Amps	With Thermal Magnetic Circuit Breaker (MCCB)	D I M	With Non Fusible Disconnect		D I M
200V	230V	460V	575V	Catalog No.	0		Catalog No.	0	Catalog No.	Price	0
2	2	5	5 ⊚	CAT7-30-*-◆-E0	Α7	15	CAT7-30-*-◆-TB15E0	E7			
2	2	5	5	CAT7-30-*-◆-E0	A7	15	CAT7-30-*-◆-TBH15E0	E7			
3	3	7.5	10 ❷	CAT7-30-*-◆-E0	A7	20	CAT7-30-*-◆-TB20E0	E7			
3	3	7.5	10	CAT7-30-*-◆-E0	A7	20	CAT7-30-*-◆-TBH20E0	E7			
~	5	10	~	CAT7-30-*-◆-E0	A7	30	CAT7-30-*-◆-TB30E0	E7			
5	~	~	15 ⊚	CAT7-30-*-◆-E0	A7	35	CAT7-30-*-◆-TB35E0	E7			
5	~	~	15	CAT7-30-*-◆-E0	A7	35	CAT7-30-*-◆-TBH35E0	E7			
~	7.5	15	20	CAT7-30-*-◆-E0	A7	40	CAT7-30-*-◆-TB40E0	E7			
~	7.5	15	20	CAT7-30-*-◆-E0	A7	40	CAT7-30-*-◆-TBH40E0	E7			
7.5	10	20	25 ❷	CAT7-30-*-◆-E0	A7	50	CAT7-30-*-◆-TB50E0	E7			
7.5	~	20	25	CAT7-30-*-◆-E0	A7	50	CAT7-30-*-◆-TBH50E0	E7			
10	10	25	30 ❷	CAT7-37-*-◆-E0	A7	50	CAT7-37-*-◆-TB50E0	E7			
10	10	~	30	CAT7-37-*-◆-E0	A7	50	CAT7-37-*-◆-TBH50E0	E7			
~	~	30	~	CAT7-43-*-◆-E0	A7	70	CAT7-43-*-◆-TB70E0	E7			
~	15	~	~	CAT7-43-*-◆-E0	A7	80	CAT7-43-*-◆-TB80E0	E7			
15	20	40	40 ❷	CAT7-55-*-◆-E0	A7	80	CAT7-55-*-◆-TB80E0	E7			
15	20	40	40	CAT7-55-*-◆-E0	A7	80	CAT7-55-*-◆-TBH80E0	E7			
~	~	~	40 ❷	CAT7-60-*-◆-E0	A7	80	CAT7-60-*-◆-TB80E0	F7			
~	~	~	40	CAT7-60-*-◆-E0	A7	80	CAT7-60-*-◆-TBH80E0	F7	To order, select equ	uivalent	
15	20	40	50 ❷	CAT7-60-*-◆-E0	A7	100	CAT7-60-*-◆-TB100E0	F7	Thermal-Magnetic		
15	20	40	50	CAT7-60-*-◆-E0	A7	100	CAT7-60-*-◆-TBH100E0	F7	Breaker catalog num		
20	25	50	60 ❷	CAT7-72-*-◆-E0	A7	125	CAT7-72-*-◆-TB125E0	F7	this chart. Specify o		
20	25	50	60	CAT7-72-*-◆-E0	A7	125	CAT7-72-*-◆-TBH125E0	F7	"With molded case :	switch.	"
25	30	60	~	CAT7-85- * -◆-E0	A7	125	CAT7-85-*-◆-TB125E0	F7			
~	~	~	75 ⊚⊙	CAT7-97-*-◆-E0	A7	150	CAT7-97-*-◆-TB150E0	F7			
~	~	~	75 ②	CAT7-97-*-◆-E0	A7	150	CAT7-97-*-◆-TBH150E0	F7			
30 🗿	~	75 ②	~	CAT7-97-*-◆-E0	A7	175	CAT7-97-*-◆-TB175E0	F7			
30	~	75	~	CAT9-116-*-◆-E0 ⊚	В7	175	CAT9-116-*-◆-TB175E0 ூ	G7			
~	40	~	100 ⊚	CAT9-116-*-◆-E0 ூ	В7	200	CAT9-116-*-◆-TB200E0 ூ	G7			
40	~	100	125 ❷	CAT9-146-*-◆-E0 ⊚	В7	225	CAT9-146-*-◆-TB225E0 ூ	G7			
~	50	~	~	CAT9-146-*-◆-E0 ூ	B7	250	CAT9-146-*-◆-TB250E0 ூ	G7			
50	60	125	150	CAT9-190-*-◆-E0 ூ	C7	300	CAT9-190-*-◆-TB300E0 ூ	H7			
60	75	150	200	CAT9-205-*-◆-E0 ⊚	C7	350	CAT9-205-*-◆-TB350E0 ூ	H7			
75	~	175	~	CAT9-265-*-◆-E0 ூ	D7	400	CAT9-265-*-◆-TB400E0 ூ	H7			
<u> </u>	100	200	250	CAT9-265-*-◆-E0 ூ	D7	450	CAT9-265-*-◆-TB450E0 ூ	H7			
100	~	~	~	CAT9-305-*-◆-E0 ூ	D7	500	CAT9-305-*-◆-TB500E0 ூ	H7			
~	125	250	300	CAT9-305-*-◆-E0 ©	D7	600	CAT9-305-*-◆-TB600E0 ூ	H7			
~	~	~	350	CAT9-370-*-◆-E0 ூ	D7	600	CAT9-370-*-◆-TB600E0 ூ	H7			
125	150	300	~	CAT9-370-*-◆-E0 ூ	D7	700	CAT9-370-*-◆-TB700E0 ூ	H7	NOTE: Catalog numbers	s and	
125	150	~	400	CAT9-400-EI-*-◆-E0	D7	700	CAT9-400-EI-*-◆-TB700E0	H7	enclosure dimensions r		
~	~	350	~	CAT9-400-EI-*-◆-E0	D7	800	CAT9-400-EI-*-◆-TB800E0	H7	contactors with AC coil		С
150	~	~	~	CAT9-460-EI-*-◆-E0	D7	800	CAT9-460-EI-*-◆-TB800E0	H7	coils, select Coil Code f		
~	200	400	500	CAT9-460-EI-*-◆-E0	D7	1000	CAT9-460-EI-*-◆-TB1000E0	H7	DC Coil Code table on p		04
200	~	~	600	CAT9-580-EI-*-◆-E0	R/F	1000	CAT9-580-EI-*-◆-TB1000E0	R/F	and follow the instruction		
~	250	500	~	CAT9-580-EI-*-◆-E0	R/F	1200	CAT9-580-EI-*-◆-TB1200E0	R/F	modifying catalog numb	bers.	
~	200	500	~	OM18-200-EI-★-◆-EU	I TV/F	1200	CMI3-200-EI-4-4-IBI200EU	J Fi/F			

Larger sizes and reversing starters available. Contact your Sprecher + Schuh representative.

Ordering Instructions

	Specify Catalog Number	
ı	Replace (★) with Coil Code Replace (◆) with O/L Relay Factory Modifications available	See page C104 See pages C105-C106 See pages C107-C111

- Dimensional information starts on page C122.
- Enclosures have gaskets for outdoor use (Type 4).
- Applicable to 600Y/347V only.
- 4 The short circuit and kAIC is relegated to the contactor's 10kA. Contact your Sprecher + Schuh representative for a higher kAIC.
- CAT9-116...CAT9-370 starters are available with "EI" option for PLC interface. Change catalog number to include "-EI". Example: CAT9-116-*-◆-TB175E0 becomes CAT9-116-EI-*-◆-TB175E0. See page C104 for price adder





NEMA Type 4/4X/7/9 Explosion Proof Pilot Device Kits

Pilot Device Kits – NEMA Type 4/4X/7/9 Applications (For use with Explosion Proof Enclosures)

			t Blocks uded		
Kits	Description	NO	NC	Catalog Number	
	START Pushbutton Green, Non-illuminated, momentary, with legend 12		0	XHPB-BT4-XNP	
	STOP Pushbutton Red, Non-illuminated, momentary, with legend 12		1	XHPB-BT5-XNP	
	DUAL Pushbutton Non-illuminated, momentary		1	XHDPB-BT1A	
	OFF-ON Selector Switch Non-illuminated, maintained, with legend		0	XHSS-1-BT4-XNP/OFF-ON	
Acres 6	HAND-AUTO Selector Switch Non-illuminated, maintained, with legend	1	1	XHSS-1-BT1A-XNP/HAND-AUTO	
	HAND-OFF-AUTO Selector Switch Non-illuminated, maintained, with legend	2	0	XHSS-3-BT2-XNP/HAND-0FF-AUT0	
	FWD-0FF-REV Selector Switch Non-illuminated, maintained, with legend		0	XHSS-3-BT2-XNP/FWD-0FF-REV	
	RED EMERGENCY STOP Pushbutton Non-illuminated, maintained push-pull, with legend		1	XHPPM-BT1A-XNP/ESTOP	
	Mechanical RESET Pushbutton	0	0	XRB	
	GUARDED Pilot Light 120V incandescent, screw terminations		nber ue ear een ed nite	XLAT-GH XLBT-GH XLCT-GH XLGT-GH XLRT-GH XLWT-GH	
	PUSHBUTTON LOCKOUT - Accessory Padlock device to activate pushbutton		~	XHPL	
	OPERATOR PROTECTIVE BOOT Rubber push button cap		een ed	XBG XBR	
	OPERATOR PROTECTIVE BOOT Rubber selector switch cap		ack	XBSB	
	COMBINATION BREATHER/DRAIN → Install on top of enclosure for Breather Install in bottom of enclosure for Drain		ss steel	XDBH2	



STOP has red background. START has green background.

One of the NPSM hole locations on the A7 dimensional enclosure could create the need for a short pilot light. Refer to factory for details.

[•] Requires purchase of 2 pcs for application of both Breather and Drain.